VISION

ACHIEVING A BALANCE BETWEEN THE NATURAL BEAUTY OF THE LAND WHERE HEALTHY ECO-SYSTEMS SUSTAIN TRADITIONAL WAYS OF LIFE AND THE NECESSITIES OF MODERN LIFE



Aרחל NVאיירחל Cree Nation Government Gouvernement de la Nation Crie

FIRE PROTECTION PLAN

FOR CABINS ON EEYOU ISTCHEE



Environment and Remedial Works Department Enhancement Program

> 284 Queen Street, Suite 202 Mistissini, Quebec G0W 1C0 (418) 923-2652 Ext: 1223

Capital Works and Services Department Fire Protection

> Oujé-Bougoumou (418) 745-2576 Ext: 225

KANT TO SAY TO PEOPLE:
 DO NOT STOP GOING OUT ON THE

LAND. IT IS OUR SOURCE OF

SURVIVAL. IT HELPS US

MENTALLY. PHYSICALLY

AND EMOTIONALLY. >>

- LEE ROY BLACKSMITH. Cree Nation Government Regional fire Marshal

M THREE TYPES OF FIRES

- Natural.
- Mechanical.
- Chemical: propane, naphtha or cloth mixed with chemicals.

WOOD STOVES

- Generally located inside cabins, tents, sheds and storage areas.
- Cabins with two sections usually have stoves in both sections.
- Place cement blocks underneath an airtight stove.
- Clean chimney stove regularly.
- Properly install the chimney
- Birch wood sticks to pipes, clean pipes often, there are logs on the market that will clean the pipes.
- Leave a 36-inch clearance between the top of the stove and the ceiling and between the walls and the stove.
- Do not hang items above the stove; do not dry clothing, wet socks, scarves, ski-pants, boot duffles or gloves above the stove.
- Look at the manufacturer's labels on the pipes.
- Keep surrounding area free of clutter.
- Cabin should be closed up underneath.
- Store hazardous materials including propane bottles, butane, gas and oil, in a safe area.

FIRE PROTECTION ITEMS

- Install a smoke detector on the ceiling, check the batteries regularly.
- Install a carbon monoxide detector 6 inches from the floor as propane leaks stay low to the floor.
- Invert and shake the dry chemical extinguishers on a regular basis to prevent the dry chemical from packing in the extinguisher.
- Fire extinguishers may not be effective in the cold if left for a long period of time.

🤹 QUICK EXIT

- A corridor or aisle across a room that leads the occupants of a cabin to an exit must be clear at all times.
- A secondary exit with a small porch to protect from snow is mandatory on all cabins; a window that opens outward may be considered a secondary exit.

CABIN EXTERIOR (SUMMER MONTHS)

- Place a 45-gallon drum that has been cut open at the top or a large tub underneath the roof to collect rain water as a source of water for extinguishing fires.
- Have on hand a water pump and hoses in the event of a fire.

HOW TO USE A FIRE EXTINGUISHER

